
THANK YOU FROM HANDWIREDPARATECH

WELCOME TO YOUR VEILSCRIBE

Thank you for choosing VEILSCRIBE, a planchette you hold in your hand. At random moments it draws one of 5,127 words and phrases and types it out on its screen. One button, no app.

GETTING STARTED

1. **Switch on** with the slide switch on the left edge. A short tune plays, then the screen says ASK A QUESTION.
2. **Ask your question, then wait.** Words come at random moments. As it arrives, the first can take up to 2½ minutes. That's normal.
3. **Write down the words you want to keep.** The screen shows the latest and the four before it. Switching off clears them.
4. **To charge,** switch off and plug a 5 V USB-C charger into the port in the back notch. There's no battery gauge, so charge before long sessions.



THE BUTTON

1 tap	SPEED	SLOW *1–4 min* › **STEADY** *35 s–2½ min* › QUICK *15–60 s* › RAPID *4–12 s*
2 taps	ALERT	**CHIME** › BELL › SOFT › SILENT *light only, for audio recording*
3 taps	LIGHT	**NORMAL** › BRIGHT › DIM › DARK *dim screen, tip light off*
4 taps	VOLUME	LOW › **MED** › HIGH
Hold 1 s	NEW SESSION	*clears the words and restarts the clock and word count*

Tap quickly: a slow second tap counts as a new single tap. Each time, the setting moves one step, looping at the end, and the screen shows it. **Underlined** is how it arrives. Settings stay when switched off.



Top row: session time, speed, sound (crossed out on SILENT), word number. **Large:** latest word. **Below:** the four before it.

★★★★★ **Enjoying your VEILSCRIBE?** Please tell others with a review on Etsy. I design and hand-build every one myself, and each review helps my little shop get found. A line or two is plenty.

Questions? Message me on Etsy: **handwiredparatech.etsy.com**

Please read. Every word is chosen at random by the electronics. There is no scientific evidence that spirits can influence it or speak through it, and no paranormal contact is promised. For curiosity and entertainment. **Lithium battery inside:** charge only with a 5 V USB charger, don't leave it charging unattended, keep it away from heat and water. Not a toy for young children.